

Fig.1

Figure 1 is a perspective view of a handheld electronic device 10. The device 10 includes a display screen 12 and a control panel 14. The control panel 14 includes a set of five circular buttons 16 and a central rectangular button 18 with two triangular symbols 20.

FIG. 2 is a perspective view of the device 10 in an open position, showing the interior of the device 10. The device 10 includes a main compartment 12 and a secondary compartment 16. The main compartment 12 is divided into two sections by a dashed line 18. The secondary compartment 16 is located at the bottom of the device 10. The device 10 also includes a control panel 14 with four circular buttons and a central display area 15.




Fig. 2




Fig. 3

FIG. 4 is a perspective view of the device 10 in a closed position.




Fig. 4